

DRIVELINE/AXLE

03
SECTION

GENERAL PROCEDURES	03-10	DIFFERENTIAL	03-14
FRONT AXLE	03-11	PROPELLER SHAFT	03-15
REAR AXLE	03-12	TECHNICAL DATA	03-50
DRIVE SHAFT	03-13	SERVICE TOOLS	03-60

03-10

03-10 GENERAL PROCEDURES

PRECAUTION (DRIVELINE/AXLE)	03-10-1
Wheels and Tires	
Removal/Installation	03-10-1

Suspension Arm	
Removal/Installation	03-10-1

PRECAUTION (DRIVELINE/AXLE)

A5U031001018W01

Wheels and Tires Removal/Installation

1. The removal and installation procedures for the wheels and tires are not mentioned in this section. When a wheel is removed, retighten it to **89—117 N·m {9.0—12.0 kgf·m, 65.1—86.7 ft·lbf}**.

Suspension Arm Removal/Installation

1. Tighten any part of the suspension that uses rubber bushings only after vehicle has been lowered and unloaded.

Note

- Unloaded... Fuel tank is full. Engine coolant and engine oil are at specified level. Spare tire, jack, and tools are in designated position.