

ALPHABETICAL INDEX

AI
SECTION

A

A/C COMPRESSOR	
REMOVAL/INSTALLATION	07-11-6
ABBREVIATIONS	00-00-24
ABS HARNESS AND INPUT SIGNAL	
INSPECTION	04-13-5
ABS HU/CM REMOVAL/INSTALLATION	04-13-4
ABS HU/CM SYSTEM INSPECTION	04-13-2
ABS ON-BOARD DIAGNOSIS	04-02-3
ABS SYSTEM DIAGRAM	04-02-2, 04-03-1, 04-13-2
ABS WHEEL-SPEED SENSOR (FRONT)	
INSPECTION	04-13-9
ABS WHEEL-SPEED SENSOR (FRONT)	
REMOVAL/INSTALLATION	04-13-8
ABS WHEEL-SPEED SENSOR (REAR)	
INSPECTION	04-13-10
ABS WHEEL-SPEED SENSOR (REAR)	
REMOVAL/INSTALLATION	04-13-10
ACCELERATOR CABLE	
INSPECTION/ADJUSTMENT	01-13-9
ACCELERATOR PEDAL (AP)	
REMOVAL/INSTALLATION	01-13-9
ACTUATOR CABLE INSTALLATION	01-20-7
ACTUATOR CABLE REMOVAL	01-20-6
AFTER REPAIR PROCEDURE	
[ENGINE CONTROL SYSTEM]	01-02A-10
AFTER REPAIR PROCEDURE [AUTOMATIC	
TRANSMISSION]	05-02-3
AFTER REPAIR PROCEDURE	
[FUEL SYSTEM]	01-14-3
AIR BAG MODULE AND PRE-TENSIONER SEAT	
BELT DEPLOYMENT AUTHORIZATION	
PROCEDURES	08-10-11
AIR BAG MODULE AND PRE-TENSIONER SEAT BELT	
DISPOSAL PROCEDURES	08-10-19
AIR BAG MODULE DEPLOYMENT	
PROCEDURE	08-10-12
AIR BAG SYSTEM LOCATION INDEX	08-10-2
AIR BAG SYSTEM SERVICE WARNINGS	08-10-3
AIR BAG SYSTEM WIRING DIAGRAM	08-02-2, 08-03-1
AIR BLEEDING [BRAKES]	04-11-3
AIR BLEEDING [STEERING]	06-12-3
AIR FILTER INSPECTION	01-16-5
ANTENNA FEEDER (FRONT) INSPECTION	09-20-6
ANTENNA FEEDER (FRONT)	
REMOVAL/INSTALLATION	09-20-6
ANTENNA FEEDER (REAR) INSPECTION	09-20-7
ANTENNA FEEDER (REAR)	
REMOVAL/INSTALLATION	09-20-7
ANTENNA MAST INSTALLATION	09-20-6
ANTENNA MAST REMOVAL	09-20-5
ANTILOCK BRAKE SYSTEM LOCATION	
INDEX	04-13-1
A-PILLAR TRIM REMOVAL/INSTALLATION	09-17-6

AUDIO AMPLIFIER	
REMOVAL/INSTALLATION	09-20-26
AUDIO RELAY REMOVAL/INSTALLATION	09-20-26
AUDIO UNIT INSTALLATION	09-20-8
AUDIO UNIT REMOVAL	09-20-7
AUTOMATIC TRANSMISSION BASIC	
INSPECTION	05-03-3
AUTOMATIC TRANSMISSION CONTROL SYSTEM	
WIRING DIAGRAM	05-02-2, 05-03-2, 05-13-4
AUTOMATIC TRANSMISSION FLUID (ATF)	
INSPECTION	05-13-8
AUTOMATIC TRANSMISSION FLUID (ATF)	
REPLACEMENT	05-13-9
AUTOMATIC TRANSMISSION LOCATION	
INDEX	05-13-2
AUTOMATIC TRANSMISSION ON-BOARD	
DIAGNOSTIC FUNCTION	05-02-3
AUTOMATIC TRANSMISSION	
REMOVAL/INSTALLATION	05-13-25
AUTOMATIC TRANSMISSION SHIFT MECHANISM	
LOCATION INDEX	05-14-1
AUTOMATIC TRANSMISSION SYMPTOM	
TROUBLESHOOTING	05-03-4
AXLE (FRONT) LOCATION INDEX	03-11-1
AXLE (REAR) LOCATION INDEX	03-12-1

B

BACK-UP LIGHT SWITCH INSPECTION	09-18-6
BACK-UP LIGHT SWITCH	
REMOVAL/INSTALLATION	09-18-6
BASE INSTALLATION	09-12-22
BASE REMOVAL	09-12-22
BASIC SYSTEM LOCATION INDEX [HVAC]	07-11-1
BATTERY INSPECTION	01-17-2
BATTERY RECHARGING	01-17-3
BATTERY REMOVAL/INSTALLATION	01-17-2
BEFORE REPAIR PROCEDURE	01-14-3
BELTLINE MOLDING (FRONT)	
REMOVAL/INSTALLATION	09-16-2
BELTLINE MOLDING	
REMOVAL/INSTALLATION	09-16-1
BLOWER MOTOR INSPECTION	07-40-6
BLOWER MOTOR	
REMOVAL/INSTALLATION	07-40-6
BLOWER UNIT DISASSEMBLY/ASSEMBLY	07-11-3
BLOWER UNIT REMOVAL/INSTALLATION	07-11-2
BODY & ACCESSORIES SST	09-60-1
BODY & ACCESSORIES TECHNICAL DATA	09-50-1
BRAKE (DISC, FRONT) INSPECTION	04-11-13
BRAKE (DISC, FRONT)	
REMOVAL/INSTALLATION	04-11-16
BRAKE (DISC, REAR) INSPECTION	04-11-20
BRAKE (DISC, REAR)	
REMOVAL/INSTALLATION	04-11-21
BRAKE PEDAL ADJUSTMENT	04-11-4

AI

ALPHABETICAL INDEX

BRAKE PEDAL INSPECTION	04-11-3
BRAKE PEDAL REMOVAL/INSTALLATION	04-11-5
BRAKE SWITCH INSPECTION	04-11-5
BRAKES SST	04-60-1
BRAKES TECHNICAL DATA	04-50-1
BUCKLE REMOVAL/INSTALLATION	08-11-2
BUCKLE SWITCH INSPECTION	08-11-3
BUMPER (FRONT) REMOVAL/INSTALLATION ...	09-10-5
BUMPER (REAR) REMOVAL/INSTALLATION ...	09-10-5

C

CALIPER (FRONT)	
DISASSEMBLY/ASSEMBLY	04-11-19
CALIPER (REAR)	
DISASSEMBLY/ASSEMBLY	04-11-23
CAMSHAFT POSITION (CMP) SENSOR	
INSPECTION	01-40-29
CAMSHAFT POSITION (CMP) SENSOR	
REMOVAL/INSTALLATION	01-40-29
CANISTER DRAIN CUT VALVE (CDCV)	
INSPECTION	01-16-6
CANISTER DRAIN CUT VALVE (CDCV)	
REMOVAL/INSTALLATION	01-16-6
CATCH TANK INSPECTION	01-16-7
CENTER PANEL REMOVAL/INSTALLATION	09-17-4
CHARCOAL CANISTER INSPECTION	01-16-6
CHARGING SYSTEM LOCATION INDEX	01-17-1
CIGARETTE LIGHTER INSPECTION	09-20-27
CIGARETTE LIGHTER	
REMOVAL/INSTALLATION	09-20-27
CLIMATE CONTROL UNIT	
DISASSEMBLY/ASSEMBLY	07-40-10
CLIMATE CONTROL UNIT INSPECTION	07-40-10
CLIMATE CONTROL UNIT INSTALLATION	07-40-9
CLIMATE CONTROL UNIT REMOVAL	07-40-8
CLIMATE CONTROL UNIT WIRE	
ADJUSTMENT	07-40-11
CLOCK SPRING ADJUSTMENT	08-10-7
CLOCK SPRING INSPECTION	08-10-8
CLOCK SPRING REMOVAL/INSTALLATION	08-10-8
CLUTCH COMPONENT LOCATION INDEX	05-10-2
CLUTCH COVER INSPECTION	05-10-13
CLUTCH DISC INSPECTION	05-10-13
CLUTCH FLUID AIR BLEEDING	05-10-3
CLUTCH FLUID INSPECTION	05-10-3
CLUTCH FLUID REPLACEMENT	05-10-3
CLUTCH MASTER CYLINDER	
DISASSEMBLY/ASSEMBLY	05-10-8
CLUTCH MASTER CYLINDER	
REMOVAL/INSTALLATION	05-10-7
CLUTCH PEDAL ADJUSTMENT	05-10-5
CLUTCH PEDAL INSPECTION	05-10-4
CLUTCH PEDAL REMOVAL/INSTALLATION	05-10-6
CLUTCH RELEASE COLLAR INSPECTION	05-10-14
CLUTCH RELEASE CYLINDER	
DISASSEMBLY/ASSEMBLY	05-10-10
CLUTCH RELEASE CYLINDER	
REMOVAL/INSTALLATION	05-10-9
CLUTCH SWITCH INSPECTION	01-40-33
CLUTCH UNIT REMOVAL/INSTALLATION	05-10-11
CODE WORD INPUT PROCEDURE	09-14-26
COIL REMOVAL/INSTALLATION	09-14-20
COLUMN COVER REMOVAL/INSTALLATION ...	09-17-4

COMBINATION LIGHT (FRONT)	
REMOVAL/INSTALLATION	09-18-2
COMBINATION LIGHT (REAR)	
REMOVAL/INSTALLATION	09-18-4
COMBINATION SWITCH	
DISASSEMBLY/ASSEMBLY	09-18-7
COMBINATION SWITCH INSPECTION	09-18-8
COMBINATION SWITCH	
REMOVAL/INSTALLATION	09-18-6
COMPRESSION INSPECTION	01-10-7
CONDENSER FAN INSPECTION	07-40-5
CONDENSER FAN	
REMOVAL/INSTALLATION	07-40-6
CONDENSER INSPECTION	07-11-7
CONDENSER REMOVAL/INSTALLATION	07-11-7
CONSOLE DISASSEMBLY/ASSEMBLY	09-17-5
CONSOLE REMOVAL/INSTALLATION	09-17-4
CONTROL SYSTEM DEVICE AND CONTROL	
RELATIONSHIP CHART	01-02A-5, 01-03-2
CONTROL SYSTEM DIAGRAM	
[ENGINE CONTROL SYSTEM]	01-40-3
CONTROL SYSTEM LOCATION INDEX	
[ENGINE CONTROL SYSTEM]	01-40-2
CONTROL SYSTEM LOCATION INDEX	
[HVAC]	07-40-2
CONTROL SYSTEM WIRING DIAGRAM	
[ENGINE CONTROL SYSTEM]	01-02A-3, 01-40-4
CONTROL VALVE BODY	
REMOVAL/INSTALLATION	05-13-32
CONVENTIONAL BRAKE SYSTEM LOCATION	
INDEX	04-11-2
CONVERTIBLE TOP ADJUSTMENT	09-16-13
CONVERTIBLE TOP	
DISASSEMBLY/ASSEMBLY	09-16-8
CONVERTIBLE TOP	
REMOVAL/INSTALLATION	09-16-7
COOLING FAN MOTOR INSPECTION	01-12-7
COOLING FAN MOTOR	
REMOVAL/INSTALLATION	01-12-7
COOLING SYSTEM LOCATION INDEX	01-12-1
COOLING SYSTEM SERVICE WARNINGS	01-12-2
COOLING UNIT DISASSEMBLY/ASSEMBLY	07-11-4
COOLING UNIT REMOVAL/INSTALLATION	07-11-3
COWL GRILLE REMOVAL/INSTALLATION	09-16-1
CRANKSHAFT POSITION (CKP) SENSOR	
ADJUSTMENT	01-40-28
CRANKSHAFT POSITION (CKP) SENSOR	
INSPECTION	01-40-27
CRANKSHAFT POSITION (CKP) SENSOR	
REMOVAL/INSTALLATION	01-40-28
CROSSMEMBER (FRONT)	
REMOVAL/INSTALLATION	02-13-13
CROSSMEMBER (REAR)	
REMOVAL/INSTALLATION	02-14-8
CROSSMEMBER BRACKET	
REMOVAL/INSTALLATION	02-14-9
CROSSMEMBER COMPONENT	
REMOVAL/INSTALLATION	02-13-14
CRUISE ACTUATOR INSPECTION	01-20-5
CRUISE ACTUATOR	
REMOVAL/INSTALLATION	01-20-5
CRUISE CONTROL MAIN SWITCH	
INSPECTION	01-20-9

ALPHABETICAL INDEX

CRUISE CONTROL MAIN SWITCH	
REMOVAL/INSTALLATION	.01-20-9
CRUISE CONTROL MODULE INSPECTION	.01-20-2
CRUISE CONTROL MODULE	
REMOVAL/INSTALLATION	.01-20-2
CRUISE CONTROL SWITCH INSPECTION	.01-20-10
CRUISE CONTROL SWITCH	
REMOVAL/INSTALLATION	.01-20-9
CRUISE CONTROL SYSTEM LOCATION	
INDEX	.01-20-1
CRUISE CONTROL SYSTEM WIRING	
DIAGRAM	01-02B-1
CRUSH ZONE SENSOR	
REMOVAL/INSTALLATION	.08-10-11
CYLINDER HEAD GASKET REPLACEMENT	.01-10-18

D

DASHBOARD DISASSEMBLY/ASSEMBLY	.09-17-3
DASHBOARD REMOVAL/INSTALLATION	.09-17-2
DESCRIPTION OF DRIVABILITY PROBLEMS	.01-03-13
DETACHABLE HARDTOP ADJUSTMENT	.09-16-21
DETACHABLE HARDTOP	
DISASSEMBLY/ASSEMBLY	.09-16-20
DIAGNOSTIC ASSIST FUNCTION [AUDIO]	.09-20-23
DIAGNOSTIC MONITORING TEST	
RESULTS	01-02A-13
DIFFERENTIAL DISASSEMBLY/ASSEMBLY	.03-14-8
DIFFERENTIAL LOCATION INDEX	.03-14-1
DIFFERENTIAL OIL INSPECTION	.03-14-2
DIFFERENTIAL OIL REPLACEMENT	.03-14-2
DIFFERENTIAL REMOVAL/INSTALLATION	.03-14-4
DISC PAD (FRONT) REPLACEMENT	.04-11-18
DISC PAD (REAR) REPLACEMENT	.04-11-22
DOOR ADJUSTMENT	.09-11-3
DOOR DISASSEMBLY/ASSEMBLY	.09-11-2
DOOR GLASS ADJUSTMENT	.09-12-2
DOOR GLASS AND GUIDE	
REMOVAL/INSTALLATION	.09-12-6
DOOR KEY CYLINDER SWITCH	
INSPECTION	.09-14-6
DOOR KEY CYLINDER SWITCH	
REMOVAL/INSTALLATION	.09-14-6
DOOR LOCK ACTUATOR INSPECTION	.09-14-5
DOOR LOCK AND OPENER	
REMOVAL/INSTALLATION	.09-14-5
DOOR LOCK CONTROL MODULE	
INSPECTION	.09-14-7
DOOR LOCK CONTROL MODULE	
REMOVAL/INSTALLATION	.09-14-7
DOOR LOCK STRIKER	
REMOVAL/INSTALLATION	.09-14-5
DOOR REMOVAL/INSTALLATION	.09-11-1
DOOR SPEAKER INSPECTION	.09-20-3
DOOR SPEAKER REMOVAL/INSTALLATION	.09-20-3
DOOR SWITCH INSPECTION	.09-18-19
DOOR SWITCH REMOVAL/INSTALLATION	.09-18-19
DOOR TRIM REMOVAL/INSTALLATION	.09-17-6
DRIVE BELT ADJUSTMENT	.01-10-4
DRIVE BELT INSPECTION	.01-10-3
DRIVE PLATE REMOVAL/INSTALLATION	.05-13-37

DRIVE SHAFT DISASSEMBLY/ASSEMBLY	.03-13-3
DRIVE SHAFT LOCATION INDEX	.03-13-1
DRIVE SHAFT PRE-INSPECTION	.03-13-1
DRIVE SHAFT REMOVAL/INSTALLATION	.03-13-2
DRIVELINE/AXLE SST	.03-60-1
DRIVELINE/AXLE TECHNICAL DATA	.03-50-1
DRIVER-SIDE AIR BAG MODULE	
REMOVAL/INSTALLATION	.08-10-5
DRL CONTROL MODULE INSPECTION	.09-18-15
DRL CONTROL MODULE	
REMOVAL/INSTALLATION	.09-18-14
DRL SYSTEM WIRING DIAGRAM	.09-18-14
DTC TABLE [AIR BAG SYSTEM]	.08-02-5
DTC TABLE [AUDIO]	.09-20-12
DTC TABLE	
[AUTOMATIC TRANSMISSION]	.05-02-5
DTC TABLE [ENGINE CONTROL SYSTEM]	.01-02A-13
DTC TABLE [IMMOBILIZER SYSTEM]	.09-02-2

E

EGR BOOST SENSOR INSPECTION	.01-40-33
EGR BOOST SENSOR SOLENOID VALVE	
INSPECTION	.01-16-10
EGR VALVE INSPECTION	.01-16-9
EGR VALVE REMOVAL/INSTALLATION	.01-16-9
ELECTRICAL SYSTEM	.00-00-16
EMERGENCY OVERRIDE BUTTON	
INSPECTION	.05-14-2
EMISSION SYSTEM LOCATION INDEX	.01-16-3
END MAT (REAR) REMOVAL/INSTALLATION	.09-17-10
ENGINE CONTROL SYSTEM OPERATION	
INSPECTION	.01-03-56
ENGINE COOLANT LEAKAGE INSPECTION	.01-12-3
ENGINE COOLANT LEVEL INSPECTION	.01-12-2
ENGINE COOLANT REPLACEMENT	.01-12-2
ENGINE COOLANT TEMPERATURE (ECT) SENSOR	
INSPECTION	.01-40-26
ENGINE DISASSEMBLY/ASSEMBLY	.01-10-26
ENGINE OIL LEVEL INSPECTION	.01-11-2
ENGINE OIL REPLACEMENT	.01-11-2
ENGINE REMOVAL/INSTALLATION	.01-10-25
ENGINE SPEED SENSING POWER STEERING	
COMPONENT LOCATION INDEX	.06-12-2
ENGINE SST	.01-60-1
ENGINE TECHNICAL DATA	.01-50-1
ENGINE TUNE-UP	.01-10-27
ENTERTAINMENT LOCATION INDEX	.09-20-2
EVAPORATIVE CHAMBER INSPECTION	.01-16-8
EVAPORATIVE EMISSION (EVAP) CONTROL	
SYSTEM LOCATION INDEX	.01-16-2
EVAPORATOR INSPECTION	.07-11-5
EXHAUST SYSTEM INSPECTION	.01-15-1
EXHAUST SYSTEM	
REMOVAL/INSTALLATION	.01-15-1
EXTENSION HOUSING	
REMOVAL/INSTALLATION	.05-13-30

F

FENDER PANEL (FRONT)	
REMOVAL/INSTALLATION	.09-10-6
FILAMENT INSPECTION	.09-12-17

ALPHABETICAL INDEX

FILAMENT REPAIR	09-12-17
FLASHER CONTROL MODULE	
INSPECTION	09-18-13
FLASHER CONTROL MODULE	
REMOVAL/INSTALLATION	09-18-12
FLOOR COVERING	
REMOVAL/INSTALLATION	09-17-10
FLUID LEVEL SENSOR INSPECTION	04-11-9
FLYWHEEL INSPECTION	05-10-15
FOG LIGHT (FRONT) ADJUSTMENT	09-18-3
FOG LIGHT (FRONT)	
REMOVAL/INSTALLATION	09-18-4
FOG LIGHT BULB (FRONT)	
REMOVAL/INSTALLATION	09-18-4
FOG LIGHT SWITCH (FRONT)	
INSPECTION	09-18-11
FOG LIGHT SWITCH (FRONT)	
REMOVAL/INSTALLATION	09-18-10
FUEL FILTER (HIGH-PRESSURE)	
REMOVAL/INSTALLATION	01-14-14
FUEL GAUGE SENDER UNIT INSPECTION.	09-22-8
FUEL INJECTOR INSPECTION.....	01-14-17
FUEL INJECTOR	
REMOVAL/INSTALLATION	01-14-17
FUEL LINE PRESSURE INSPECTION	01-14-4
FUEL LINE SAFETY PROCEDURE.....	01-03-13
FUEL PRESSURE HOLD INSPECTION	01-14-5
FUEL PRESSURE RELEASE AND SERVICING FUEL	
SYSTEM.....	01-03-13
FUEL PUMP (FP)	
DISASSEMBLY/ASSEMBLY	01-14-11
FUEL PUMP (FP) INSPECTION.....	01-14-12
FUEL PUMP (FP)	
REMOVAL/INSTALLATION	01-14-10
FUEL SHUT-OFF VALVE/ROLLOVER VALVE	
INSPECTION	01-16-4
FUEL SYSTEM LOCATION INDEX	01-14-2
FUEL TANK PRESSURE (FTP) SENSOR	
INSPECTION	01-40-25
FUEL TANK REMOVAL/INSTALLATION.....	01-14-6
FUEL-FILLER CAP INSPECTION	01-16-3
FUEL-FILLER LID ADJUSTMENT	09-10-1
FUEL-FILLER LID OPENER	
REMOVAL/INSTALLATION	09-14-14
FUEL-FILLER LID REMOVAL/INSTALLATION ...	09-10-1
FUNDAMENTAL PROCEDURES.....	00-00-11
FUSE SERVICE CAUTION.....	09-21-1

G

GENERAL PROCEDURES [CLUTCH].....	05-10-3
GENERATOR INSPECTION	01-17-4
GENERATOR REMOVAL/INSTALLATION	01-17-3
GLOVE COMPARTMENT	
REMOVAL/INSTALLATION	09-17-5

H

HAZARD WARNING SWITCH INSPECTION.	09-18-10
HAZARD WARNING SWITCH	
REMOVAL/INSTALLATION	09-18-9
HEADER TRIM (FRONT)	
REMOVAL/INSTALLATION	09-17-7

HEADLIGHT ADJUSTMENT.....	09-18-2
HEADLIGHT BULB	
REMOVAL/INSTALLATION	09-18-2
HEADLIGHT RELAY	
REMOVAL/INSTALLATION	09-18-11
HEATED OXYGEN SENSOR (HO2S) HEATER	
INSPECTION	01-40-32
HEATED OXYGEN SENSOR (HO2S)	
INSPECTION	01-40-31
HEATER CORE INSPECTION	07-11-6
HEATER UNIT	
DISASSEMBLY/ASSEMBLY.....	07-11-6
HEATER UNIT REMOVAL/INSTALLATION	07-11-5
HEATER, VENTILATION & AIR CONDITIONING	
(HVAC) SST	07-60-1
HEATER, VENTILATION & AIR CONDITIONING	
(HVAC) TECHNICAL DATA	07-50-1
HIGH-MOUNT BRAKE LIGHT	
REMOVAL/INSTALLATION	09-18-5
HOOD ADJUSTMENT.....	09-10-2
HOOD LOCK AND OPENER	
REMOVAL/INSTALLATION	09-14-15
HOOD REMOVAL/INSTALLATION.....	09-10-2
HORN REMOVAL/INSTALLATION.....	09-22-8
HOW TO USE THIS MANUAL	00-00-1

I

IDENTIFICATION NUMBER LOCATIONS	00-00-23
IDLE AIR CONTROL (IAC) VALVE	
INSPECTION	01-13-5
IDLE AIR CONTROL (IAC) VALVE	
REMOVAL/INSTALLATION	01-13-5
IGNITION COIL INSPECTION	01-18-2
IGNITION COIL REMOVAL/INSTALLATION	01-18-2
IGNITION SWITCH INSPECTION	09-21-3
IGNITION SWITCH REMOVAL/INSTALLATION ...	09-21-2
IGNITION SYSTEM LOCATION INDEX	01-18-1
IMMOBILIZER SYSTEM LOCATION INDEX	09-14-18
IMMOBILIZER SYSTEM REPROGRAM	
PROCEDURE	09-14-20
IMMOBILIZER SYSTEM SERVICE CAUTION ...	09-14-18
IMMOBILIZER SYSTEM WIRING DIAGRAM.....	09-02-1
IMMOBILIZER UNIT INSPECTION.....	09-14-19
IMMOBILIZER UNIT	
REMOVAL/INSTALLATION	09-14-19
INPUT/TURBINE SPEED SENSOR	
INSPECTION	05-13-16
INPUT/TURBINE SPEED SENSOR	
REMOVAL/INSTALLATION	05-13-16
INSPECTION OF DTCS FOR CONDITION	
DETECTION MODE	01-02B-7
INSPECTION OF DTCS FOR OPERATION	
MODE	01-02B-2
INSPECTION OF SST	
(DEPLOYMENT TOOL)	08-10-19
INSPECTION ORDER	
(CRUISE CONTROL SYSTEM)	01-02B-2
INSTALLATION OF RADIO SYSTEM.....	00-00-16
INSTRUMENT CLUSTER	
DISASSEMBLY/ASSEMBLY.....	09-22-3
INSTRUMENT CLUSTER INPUT/OUTPUT CHECK	
MODE	09-22-5
INSTRUMENT CLUSTER INSPECTION	09-22-3

ALPHABETICAL INDEX

INSTRUMENT CLUSTER
REMOVAL/INSTALLATION09-22-3
INSTRUMENT CLUSTER SYSTEM WIRING
DIAGRAM09-22-2
INTAKE AIR TEMPERATURE (IAT) SENSOR
INSPECTION.....01-40-22
INTAKE-AIR SYSTEM LOCATION INDEX01-13-2
INTAKE-AIR SYSTEM
REMOVAL/INSTALLATION01-13-3
INTERIOR LIGHT INSPECTION.....09-18-17
INTERIOR LIGHT REMOVAL/INSTALLATION...09-18-17
INTERMITTENT CONCERN
TROUBLESHOOTING01-03-4

J

JACKING POSITIONS.....00-00-21

K

KEY INTERLOCK SOLENOID INSPECTION05-14-2
KEY INTERLOCK SOLENOID
REMOVAL/INSTALLATION05-14-2
KEY INTERLOCK UNIT INSPECTION05-14-2
KEY INTERLOCK UNIT
REMOVAL/INSTALLATION05-14-3
KEY REMINDER SWITCH INSPECTION09-21-3
KEYLESS CONTROL MODULE ID CODE
CHANGE09-14-11
KEYLESS CONTROL MODULE INSPECTION....09-14-9
KEYLESS CONTROL MODULE
REMOVAL/INSTALLATION09-14-9
KEYLESS ENTRY SYSTEM CHECK
SHEET.....09-03A-3
KEYLESS ENTRY SYSTEM PRELIMINARY
INSPECTION.....09-03A-4
KEYLESS ENTRY SYSTEM WIRING
DIAGRAM09-03A-1
KEYLESS ENTRY SYSTEM WIRING
DIAGRAM09-14-4
KNOCK SENSOR (KS) INSPECTION.....01-40-31
KNOCK SENSOR (KS)
REMOVAL/INSTALLATION01-40-30

L

LICENSE PLATE LIGHT
REMOVAL/INSTALLATION09-18-5
LOWER ARM (FRONT) INSPECTION02-13-9
LOWER ARM (FRONT)
REMOVAL/INSTALLATION02-13-7
LOWER ARM (REAR)
REMOVAL/INSTALLATION02-14-4
LOWER MODULE
REMOVAL/INSTALLATION09-20-9
LOWER PANEL REMOVAL/INSTALLATION09-17-5
LUBRICATION SYSTEM LOCATION INDEX01-11-1

M

MAGNETIC CLUTCH ADJUSTMENT07-40-4

MAGNETIC CLUTCH
DISASSEMBLY/ASSEMBLY07-40-4
MAGNETIC CLUTCH INSPECTION07-40-3
MAIN FUSE REMOVAL/INSTALLATION.....09-21-1
MANUAL STEERING COMPONENT LOCATION
INDEX06-11-1
MANUAL TRANSMISSION [M15M-D] LOCATION
INDEX05-11A-2
MANUAL TRANSMISSION [Y16M-D] LOCATION
INDEX05-11B-1
MANUAL TRANSMISSION
REMOVAL/INSTALLATION [M15M-D]05-11A-4
MANUAL TRANSMISSION
REMOVAL/INSTALLATION [Y16M-D].....05-11B-3
MASS AIR FLOW (MAF) SENSOR
INSPECTION01-40-24
MASTER CYLINDER
DISASSEMBLY/ASSEMBLY04-11-9
MASTER CYLINDER
REMOVAL/INSTALLATION.....04-11-6
MECHANICAL LOCATION INDEX01-10-2
MECHANICAL SYSTEM TEST05-13-5
METER HOOD REMOVAL/INSTALLATION09-17-6

N

NEUTRAL SWITCH INSPECTION.....01-40-34
NONRETURN VALVE INSPECTION.....01-14-10

O

O/D OFF SWITCH INSPECTION.....05-13-13
O/D OFF SWITCH
REMOVAL/INSTALLATION.....05-13-14
OBD-II DIAGNOSTIC MONITORING TEST
RESULTS.....01-02A-8
OBD-II DRIVE MODE.....01-02A-10
OBD-II FREEZE FRAME DATA.....01-02A-7
OBD-II ON-BOARD SYSTEM READINESS
TEST01-02A-7
OBD-II PARAMETER IDENTIFICATION (PID)
ACCESS01-02A-8
OBD-II PENDING TROUBLE CODES.....01-02A-7
OBD-II READ/CLEAR DIAGNOSTIC TEST
RESULTS.....01-02A-8
OIL CONTROL VALVE (OCV) INSPECTION01-10-8
OIL CONTROL VALVE (OCV)
REMOVAL/INSTALLATION.....01-10-8
OIL COOLER REMOVAL/INSTALLATION
[AUTOMATIC TRANSMISSION]05-13-35
OIL COOLER REMOVAL/INSTALLATION
[ENGINE]01-11-4
OIL FILTER REPLACEMENT01-11-3
OIL PAN REMOVAL/INSTALLATION01-11-4
OIL PRESSURE INSPECTION01-11-3
OIL PRESSURE SWITCH INSPECTION.....09-22-8
OIL PUMP DISASSEMBLY/ASSEMBLY01-11-10
OIL PUMP INSPECTION.....01-11-10
OIL PUMP REMOVAL/INSTALLATION.....01-11-9
OIL SEAL (FRONT) REPLACEMENT [ENGINE]..01-10-23
OIL SEAL (REAR) REPLACEMENT [ENGINE]...01-10-24
OIL SEAL (REAR) REPLACEMENT
[M15M-D]05-11A-4

AI

ALPHABETICAL INDEX

OIL SEAL (REAR) REPLACEMENT [Y16M-D]	05-11B-3
OIL SEAL REPLACEMENT [DIFFERENTIAL]	03-14-2
OIL SEAL REPLACEMENT [TRANSMISSION]	05-13-31
ON-BOARD DIAGNOSTIC FUNCTION [KEYLESS ENTRY SYSTEM]	09-03A-5
ON-BOARD DIAGNOSTIC TEST [ENGINE CONTROL SYSTEM]	01-02A-8
OUTLINE [CRUISE CONTROL SYSTEM]	01-02B-2
OUTPUT SPEED SENSOR INSPECTION	05-13-17
OUTPUT SPEED SENSOR REMOVAL/INSTALLATION	05-13-17
OUTSIDE MIRROR GLASS INSTALLATION	09-12-19
OUTSIDE MIRROR GLASS REMOVAL	09-12-19

P

P POSITION SWITCH INSPECTION	05-14-3
PACKAGE TRIM (REAR) REMOVAL/INSTALLATION	09-17-7
PANEL LIGHT CONTROL SWITCH INSPECTION	09-18-20
PANEL LIGHT CONTROL SWITCH REMOVAL/INSTALLATION	09-18-19
PARKING BRAKE ADJUSTMENT	04-12-1
PARKING BRAKE CABLE REMOVAL/INSTALLATION	04-12-2
PARKING BRAKE INSPECTION	04-12-1
PARKING BRAKE LEVER REMOVAL/INSTALLATION	04-12-1
PASSENGER AIR BAG DEACTIVATION (PAD) SWITCH INSPECTION	08-10-9
PASSENGER AIR BAG DEACTIVATION (PAD) SWITCH REMOVAL/INSTALLATION	08-10-9
PASSENGER AIR BAG DEACTIVATION (PAD) SWITCH WARNING LIGHT BULB AND PASSENGER AIR BAG DEACTIVATION (PAD) SWITCH ILLUMINATION BULB REMOVAL/INSTALLATION	08-10-10
PASSENGER-SIDE AIR BAG MODULE REMOVAL/INSTALLATION	08-10-6
PCM INSPECTION	01-40-6
PCM REMOVAL/INSTALLATION	01-40-6
PCV VALVE INSPECTION	01-16-10
PILOT BEARING INSPECTION	05-10-14
PLATE REMOVAL/INSTALLATION	01-40-29
POWER ANTENNA DISASSEMBLY/ASSEMBLY	09-20-5
POWER ANTENNA INSPECTION	09-20-5
POWER ANTENNA REMOVAL/INSTALLATION	09-20-4
POWER BRAKE UNIT INSPECTION	04-11-10
POWER BRAKE UNIT REMOVAL/INSTALLATION	04-11-12
POWER DOOR LOCK SYSTEM LOCATION INDEX	09-14-2
POWER DOOR LOCK SYSTEM WIRING DIAGRAM	09-14-3
POWER OUTSIDE MIRROR INSPECTION	09-12-19
POWER OUTSIDE MIRROR REMOVAL/INSTALLATION	09-12-18
POWER OUTSIDE MIRROR SWITCH INSPECTION	09-12-21

POWER OUTSIDE MIRROR SWITCH REMOVAL/INSTALLATION	09-12-20
POWER STEERING FLUID INSPECTION	06-12-3
POWER STEERING OIL PUMP DISASSEMBLY/ASSEMBLY	06-12-17
POWER STEERING OIL PUMP REMOVAL/INSTALLATION	06-12-16
POWER STEERING PRESSURE (PSP) SWITCH INSPECTION	01-40-35
POWER WINDOW MOTOR INSPECTION	09-12-9
POWER WINDOW REGULATOR ASSEMBLY	09-12-8
POWER WINDOW REGULATOR DISASSEMBLY	09-12-7
POWER WINDOW REGULATOR REMOVAL/INSTALLATION	09-12-7
POWER WINDOW SWITCH INSPECTION	09-12-10
POWER WINDOW SWITCH REMOVAL/INSTALLATION	09-12-10
POWER WINDOW SYSTEM LOCATION INDEX	09-12-1
PRECAUTION [ABS]	04-03-2
PRECAUTION [BRAKES]	04-10-1
PRECAUTION [DRIVELINE/AXLE]	03-10-1
PRECAUTION [STEERING]	06-10-1
PRECAUTION [SUSPENSION]	02-10-1
PRE-DELIVERY INSPECTION	00-00-25
PRESSURE REGULATOR INSPECTION	01-14-20
PRESSURE REGULATOR REMOVAL/INSTALLATION	01-14-20
PROPELLER SHAFT INSPECTION	03-15-3
PROPELLER SHAFT LOCATION INDEX	03-15-1
PROPELLER SHAFT REMOVAL/INSTALLATION	03-15-2
PROPORTIONING BYPASS VALVE (WITHOUT ABS) OR BRAKE PIPE JOINT (WITH ABS) REPLACEMENT	04-11-13
PROPORTIONING BYPASS VALVE INSPECTION [WITHOUT ABS]	04-11-12
PULSATION DAMPER NO.1 REMOVAL/INSTALLATION	01-14-20
PULSATION DAMPER NO.1, NO.2 INSPECTION	01-14-20
PULSATION DAMPER NO.2 REMOVAL/INSTALLATION	01-14-20
PURGE SOLENOID VALVE INSPECTION	01-16-8
PURGE SOLENOID VALVE REMOVAL/INSTALLATION	01-16-7

Q

QUARTER TRIM REMOVAL/INSTALLATION	09-17-7
---	---------

R

RADIATOR CAP INSPECTION	01-12-4
RADIATOR REMOVAL/INSTALLATION	01-12-4
REARVIEW MIRROR INSTALLATION	09-12-21
REARVIEW MIRROR REMOVAL	09-12-21
REFRIGERANT CHARGE CHECK	07-10-2
REFRIGERANT CHARGING	07-10-4
REFRIGERANT LINES REMOVAL/INSTALLATION	07-11-8
REFRIGERANT PRESSURE CHECK	07-10-3

ALPHABETICAL INDEX

REFRIGERANT PRESSURE SWITCH INSPECTION	07-40-7
REFRIGERANT PRESSURE SWITCH REMOVAL/INSTALLATION	07-40-7
REFRIGERANT RECOVERY	07-10-3
REFRIGERANT SYSTEM GENERAL PROCEDURES	07-10-2
REFRIGERANT SYSTEM PERFORMANCE TEST	07-10-2
REFRIGERANT SYSTEM SERVICE CAUTIONS	07-10-1
REFRIGERANT SYSTEM SERVICE WARNINGS	07-10-1
RELAY INSPECTION	09-21-5
RELAY LOCATION	09-21-4
RESISTOR INSPECTION	07-40-3
RESISTOR REMOVAL/INSTALLATION	07-40-3
RESTRAINTS SST	08-60-1
RETAINER ADJUSTMENT	09-16-13
ROAD TEST	05-13-7
ROOM FUSE INSTALLATION	09-21-2

S

SAE STANDARDS	00-00-23
SAS CONTROL MODULE REMOVAL/INSTALLATION	08-10-10
SCHEDULED MAINTENANCE	00-00-27
SCUFF PLATE REMOVAL/INSTALLATION	09-17-8
SEAT BELT INSPECTION	08-11-2
SEAT BELT REMOVAL/INSTALLATION	08-11-1
SEAT DISASSEMBLY/ASSEMBLY	09-13-2
SEAT REMOVAL/INSTALLATION	09-13-1
SELECTOR LEVER ADJUSTMENT	05-14-6
SELECTOR LEVER DISASSEMBLY/ASSEMBLY	05-14-8
SELECTOR LEVER INSPECTION	05-14-5
SELECTOR LEVER REMOVAL/INSTALLATION	05-14-7
SHIFT-LOCK ACTUATOR INSPECTION	05-14-4
SHIFT-LOCK ACTUATOR REMOVAL/INSTALLATION	05-14-5
SHOCK ABSORBER (FRONT) DISPOSAL	02-13-6
SHOCK ABSORBER (FRONT) INSPECTION	02-13-6
SHOCK ABSORBER (REAR) DISPOSAL	02-14-3
SHOCK ABSORBER (REAR) INSPECTION	02-14-3
SHOCK ABSORBER AND COIL SPRING (FRONT) REMOVAL/INSTALLATION	02-13-3
SHOCK ABSORBER AND COIL SPRING (REAR) REMOVAL/INSTALLATION	02-14-2
SIDE MARKER LIGHT (FRONT) REMOVAL/INSTALLATION	09-18-3
SIDE TRIM (FRONT) REMOVAL/INSTALLATION	09-17-8
SOLENOID VALVES INSPECTION	05-13-17
SOLENOID VALVES REMOVAL/INSTALLATION	05-13-18
SPARK PLUG INSPECTION	01-18-3
SPARK PLUG REMOVAL/INSTALLATION	01-18-3
STABILIZER (FRONT) REMOVAL/INSTALLATION	02-13-12
STABILIZER (REAR) REMOVAL/INSTALLATION	02-14-7

STABILIZER CONTROL LINK (FRONT) INSPECTION	02-13-13
STABILIZER CONTROL LINK (REAR) INSPECTION	02-14-8
STARTER DISASSEMBLY/ASSEMBLY	01-19-7
STARTER INSPECTION	01-19-2
STARTER INTERLOCK SWITCH INSPECTION [MT]	01-19-8
STARTER REMOVAL/INSTALLATION	01-19-2
STARTING PROCEDURE FOR ON-BOARD DIAGNOSTIC TEST MODE	09-20-10
STARTING SYSTEM LOCATION INDEX	01-19-1
STEERING GEAR AND LINKAGE DISASSEMBLY/ASSEMBLY [ENGINE SPEED SENSING POWER STEERING]	06-12-8
STEERING GEAR AND LINKAGE DISASSEMBLY/ASSEMBLY [MANUAL STEERING]	06-11-7
STEERING GEAR AND LINKAGE INSPECTION [ENGINE SPEED SENSING POWER STEERING]	06-12-16
STEERING GEAR AND LINKAGE INSPECTION [MANUAL STEERING]	06-11-14
STEERING GEAR AND LINKAGE REMOVAL/INSTALLATION [ENGINE SPEED SENSING POWER STEERING]	06-12-7
STEERING GEAR AND LINKAGE REMOVAL/INSTALLATION [MANUAL STEERING]	06-11-6
STEERING SHAFT DISASSEMBLY/ASSEMBLY [ENGINE SPEED SENSING POWER STEERING]	06-12-6
STEERING SHAFT DISASSEMBLY/ASSEMBLY [MANUAL STEERING]	06-11-4
STEERING SHAFT INSPECTION [ENGINE SPEED SENSING POWER STEERING]	06-12-6
STEERING SHAFT INSPECTION [MANUAL STEERING]	06-11-5
STEERING SST	06-60-1
STEERING TECHNICAL DATA	06-50-1
STEERING WHEEL AND COLUMN INSPECTION [ENGINE SPEED SENSING POWER STEERING]	06-12-5
STEERING WHEEL AND COLUMN INSPECTION [MANUAL STEERING]	06-11-2
STEERING WHEEL AND COLUMN REMOVAL/INSTALLATION [ENGINE SPEED SENSING POWER STEERING]	06-12-6
STEERING WHEEL AND COLUMN REMOVAL/INSTALLATION [MANUAL STEERING]	06-11-3
STRUT BAR (FRONT) REMOVAL/INSTALLATION	02-13-2
SUPPLIER IDENTIFICATION PROCEDURE [AUDIO UNIT]	09-20-10
SUSPENSION (FRONT) LOCATION INDEX	02-13-2
SUSPENSION (REAR) LOCATION INDEX	02-14-1
SUSPENSION SST	02-60-1
SUSPENSION TECHNICAL DATA	02-50-1
SYMPTOM DIAGNOSTIC INDEX [ENGINE CONTROL SYSTEM]	01-03-6
SYMPTOM QUICK DIAGNOSTIC CHART [ENGINE CONTROL SYSTEM]	01-03-9
SYMPTOM TROUBLESHOOTING [BRAKES]	04-03-3

ALPHABETICAL INDEX

T

TAPPET AND ADJUSTMENT SHIM	
REMOVAL/INSTALLATION	01-10-20
THERMOSTAT INSPECTION	01-12-6
THERMOSTAT REMOVAL/INSTALLATION	01-12-5
THERMOSWITCH INSPECTION	07-40-7
THREWAY CATALYTIC CONVERTER (TWC)	
INSPECTION	01-16-11
THROTTLE CABLE ADJUSTMENT	05-13-10
THROTTLE CABLE INSPECTION	05-13-10
THROTTLE CABLE	
REMOVAL/INSTALLATION	05-13-11
THROTTLE POSITION (TP) SENSOR	
INSPECTION	01-40-24
THROTTLE POSITION (TP) SENSOR	
REPLACEMENT	01-40-25
TIMING BELT REMOVAL/INSTALLATION	01-10-10
TNS RELAY REMOVAL/INSTALLATION	09-18-12
TOP FABRIC REMOVAL/INSTALLATION	09-16-14
TOP FABRIC REPAIR	09-16-18
TORQUE CONVERTER	
REMOVAL/INSTALLATION	05-13-34
TOWING	00-00-22
TRANSMISSION CONTROL MODULE (TCM)	
INSPECTION	05-13-20
TRANSMISSION CONTROL MODULE (TCM)	
REMOVAL/INSTALLATION	05-13-24
TRANSMISSION OIL INSPECTION [M15M-D]	05-11A-3
TRANSMISSION OIL INSPECTION [Y16M-D]	05-11B-2
TRANSMISSION OIL REPLACEMENT	
[M15M-D]	05-11A-3
TRANSMISSION OIL REPLACEMENT	
[Y16M-D]	05-11B-2
TRANSMISSION RANGE (TR) SWITCH	
ADJUSTMENT	05-13-16
TRANSMISSION RANGE (TR) SWITCH	
INSPECTION	05-13-14
TRANSMISSION RANGE (TR) SWITCH	
REMOVAL/INSTALLATION	05-13-15
TRANSMISSION/TRANSAXLE SST	05-60-1
TRANSMISSION/TRANSAXLE TECHNICAL	
DATA	05-50-1
TRANSMITTER BATTERY INSPECTION	09-14-13
TRANSMITTER BATTERY REPLACEMENT	09-14-12
TROUBLESHOOTING INDEX	
[AIR BAG SYSTEM]	08-03-2
TROUBLESHOOTING INDEX [AUDIO]	09-03B-1
TROUBLESHOOTING INDEX [HVAC]	07-03-1
TROUBLESHOOTING INDEX	
[POWER DOOR LOCK SYSTEM]	09-03A-5
TRUNK COMPARTMENT LIGHT SWITCH	
INSPECTION	09-18-18
TRUNK END TRIM	
REMOVAL/INSTALLATION	09-17-8
TRUNK LID ADJUSTMENT	09-10-4
TRUNK LID LOCK ACTUATOR INSPECTION	09-14-17
TRUNK LID LOCK AND OPENER	
REMOVAL/INSTALLATION	09-14-15
TRUNK LID OPENER RELAY	
REMOVAL/INSTALLATION	09-14-17
TRUNK LID REMOVAL/INSTALLATION	09-10-3
TRUNK LID STRIKER	

REMOVAL/INSTALLATION	09-14-17
TRUNK SIDE TRIM	
REMOVAL/INSTALLATION	09-17-9
TURN LIGHT/PARKING LIGHT BULB (FRONT)	
REMOVAL/INSTALLATION	09-18-3
TWEETER INSPECTION	09-20-4
TWEETER REMOVAL/INSTALLATION	09-20-3

U

UNITS	00-00-11
UPPER ARM (FRONT) INSPECTION	02-13-12
UPPER ARM (FRONT)	
REMOVAL/INSTALLATION	02-13-10
UPPER ARM (REAR)	
REMOVAL/INSTALLATION	02-14-6
UPPER MODULE REMOVAL/INSTALLATION	09-20-8

V

VACUUM HOSE ROUTING DIAGRAM	01-13-3
VACUUM LINE INSPECTION	04-11-3
VALVE CLEARANCE ADJUSTMENT	01-10-5
VALVE CLEARANCE INSPECTION	01-10-4
VARIABLE TUMBLE CONTROL SYSTEM (VTCS)	
CHECK VALVE (ONE-WAY), DELAY VALVE	
INSPECTION	01-13-6
VARIABLE TUMBLE CONTROL SYSTEM (VTCS)	
CHECK VALVE (ONE-WAY), DELAY VALVE	
REMOVAL/INSTALLATION	01-13-6
VARIABLE TUMBLE CONTROL SYSTEM (VTCS)	
SHUTTER VALVE ACTUATOR INSPECTION	01-13-7
VARIABLE TUMBLE CONTROL SYSTEM (VTCS)	
SHUTTER VALVE ACTUATOR	
REMOVAL/INSTALLATION	01-13-6
VARIABLE TUMBLE CONTROL SYSTEM (VTCS)	
SOLENOID VALVE INSPECTION	01-13-8
VARIABLE TUMBLE CONTROL SYSTEM (VTCS)	
SOLENOID VALVE	
REMOVAL/INSTALLATION	01-13-7
VARIABLE TUMBLE CONTROL SYSTEM (VTCS)	
VACUUM SWITCH INSPECTION	01-13-8
VARIABLE VALVE TIMING ACTUATOR	
INSPECTION	01-10-9
VEHICLE LIFT (2 SUPPORTS) AND SAFETY STAND	
(RIGID RACK) POSITION	00-00-21
VEHICLE SPEEDOMETER SENSOR INSPECTION	
[M15M-D]	05-11A-4
VEHICLE SPEEDOMETER SENSOR INSPECTION	
[Y16M-D]	05-11B-3
VEHICLE SPEEDOMETER SENSOR	
REMOVAL/INSTALLATION [M15M-D]	05-11A-4
VEHICLE SPEEDOMETER SENSOR	
REMOVAL/INSTALLATION [Y16M-D]	05-11B-3

W

WARNING AND INDICATOR LIGHT BULB	
REMOVAL/INSTALLATION	09-22-8
WATER PUMP REMOVAL/INSTALLATION	01-12-6
WHEEL (FRONT) ALIGNMENT	02-11-1
WHEEL (REAR) ALIGNMENT	02-11-4
WHEEL ALIGNMENT PRE-INSPECTION	02-11-1

ALPHABETICAL INDEX

WHEEL BALANCE ADJUSTMENT	02-12-1	WINDSHIELD WASHER MOTOR INSPECTION	09-19-6
WHEEL HUB AND KNUCKLE PRE-INSPECTION	03-12-1	WINDSHIELD WASHER MOTOR REMOVAL/INSTALLATION	09-19-5
WHEEL HUB AND KNUCKLE REMOVAL/INSTALLATION	03-12-2	WINDSHIELD WASHER NOZZLE ADJUSTMENT	09-19-6
WHEEL HUB AND STEERING KNUCKLE PRE-INSPECTION	03-11-1	WINDSHIELD WASHER NOZZLE CLEANING	09-19-6
WHEEL HUB AND STEERING KNUCKLE REMOVAL/INSTALLATION	03-11-2	WINDSHIELD WASHER NOZZLE INSTALLATION	09-19-7
WHEEL HUB BOLT REPLACEMENT	03-11-2	WINDSHIELD WASHER NOZZLE REMOVAL	09-19-7
WINDOW DEFROSTER (REAR) LOCATION INDEX	09-12-2	WINDSHIELD WASHER TANK REMOVAL/INSTALLATION	09-19-5
WINDOW DEFROSTER SWITCH (REAR) INSPECTION	09-12-18	WINDSHIELD WIPER ARM AND BLADE ADJUSTMENT	09-19-2
WINDOW GLASS (REAR) INSTALLATION	09-12-11	WINDSHIELD WIPER ARM AND BLADE REMOVAL/INSTALLATION	09-19-2
WINDOW GLASS (REAR) REMOVAL	09-12-10	WINDSHIELD WIPER LINK REMOVAL/INSTALLATION	09-19-3
WINDOW MOLDING (REAR) INSTALLATION	09-16-2	WINDSHIELD WIPER MOTOR INSPECTION	09-19-4
WINDOW MOLDING (REAR) REMOVAL	09-16-2	WINDSHIELD WIPER MOTOR REMOVAL/INSTALLATION	09-19-3
WINDSHIELD INSTALLATION	09-12-15	WIPER/WASHER SYSTEMS LOCATION INDEX	09-19-1
WINDSHIELD MOLDING INSTALLATION	09-16-4	WIPER/WASHER SYSTEMS WIRING DIAGRAM	09-19-2
WINDSHIELD MOLDING REMOVAL	09-16-4		
WINDSHIELD REMOVAL	09-12-13		
WINDSHIELD WASHER HOSE REMOVAL/INSTALLATION	09-19-7		