


REMOTE CONTROL MIRROR



SERVICE HINTS

R7 REMOTE CONTROL MIRROR SW

- 8-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position
- 6-7 : Continuity with the operation SW at **UP** or **LEFT** position
- 5-7 : Continuity with the operation SW at **RIGHT** position and the select SW at **LH** position
- 4-7 : Continuity with the operation SW at **DOWN** position and the select SW at **LH** position
- 2-7 : Continuity with the operation SW at **RIGHT** position and the select SW at **RH** position
- 3-7 : Continuity with the operation SW at **DOWN** position and the select SW at **RH** position

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
R7	33	R10	35	R11	35

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
3	24	R/B No.3 (Left Side of Instrument Panel)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
6D	26	Instrument Panel Wire and J/B No.6 (Instrument Panel Brace LH)
6E		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	38	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
II1	40	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
IE	38	Left Kick Panel

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I2	40	Instrument Panel Wire			