

SERVICE HINTS

R3 RADIO AND PLAYER

4-GROUND : Always approx. **12** volts

3-GROUND : Approx. **12** volts with the ignition SW at **ACC** or **ON** position

7-GROUND : Always continuity

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A17	34	F4	34	T5	35
F3	34	R3	33	T6	35

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
3	24	R/B No.3 (Left Side of Instrument Panel)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
6E	26	Instrument Panel Wire and J/B No.6 (Instrument Panel Brace LH)
6F		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	38	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
II1	40	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IJ1	40	Floor Wire and Instrument Panel Wire (Right Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
IG	38	Instrument Panel Brace RH