

<b>DTC</b>	<b>B0137/71</b>	<b>Short in P/T Squib (LH) Circuit (to Ground)</b>
------------	-----------------	--

## CIRCUIT DESCRIPTION

The P/T squib (LH) circuit consists of the airbag sensor assembly and seat belt pretensioner (LH). It causes the SRS to deploy when the SRS deployment conditions are satisfied.

For details of the function of each component, see OPERATION on page RS-2.

DTC B0137/71 is recorded when a ground short is detected in the P/T squib (LH) circuit.


DTC No.	DTC Detection Condition	Trouble Area
B0137/71	<ul style="list-style-type: none"> <li>• Short circuit in P/T squib (LH) wire harness (to ground)</li> <li>• P/T squib (LH) malfunction</li> <li>• Airbag sensor assembly malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Wire harness</li> <li>• Seat belt pretensioner (P/T squib) (LH)</li> <li>• Airbag sensor assembly</li> </ul>

## WIRING DIAGRAM


See page DI-294.

## INSPECTION PROCEDURE

<b>1</b>	<b>Prepare for inspection (See step 1 on page DI-323).</b>
----------	--



<b>2</b>	<b>Check P/T squib (LH) circuit.</b>
----------	--------------------------------------



### **CHECK:**

For the connector (on the seat belt pretensioner side) between the seat belt pretensioner (LH) and the airbag sensor assembly, measure the resistance between PL+ and body ground.

### **OK:**


**Resistance: 1 MΩ or Higher**

**NG**

**Repair or replace harness or connector between seat belt pretensioner (LH) and airbag sensor assembly.**

**OK**

### 3 Check airbag sensor assembly.



#### PREPARATION:

- Connect the connector to the airbag sensor assembly.
- Using a service wire, connect terminals PL+ and PL- of the connector (on the seat belt pretensioner side) between the seat belt pretensioner (LH) and the airbag sensor assembly.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

#### CHECK:

- Turn the ignition switch ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See step 5 on page [DI-237](#)).
- Turn the ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the ignition switch ON, and wait at least for 20 seconds.
- Check the DTC (See page [DI-237](#)).

#### OK:

**DTC B0137/71 is not output.**

#### HINT:


Codes other than code B0137/71 may be output at this time, but they are not relevant to this check.

**NG**

**Replace airbag sensor assembly.**

**OK**

#### 4 Check P/T squib (LH).



#### PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect the negative (–) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the seat belt pretensioner (LH) connector.
- Connect the negative (–) terminal cable to the battery, and wait at least for 2 seconds.

#### CHECK:

- Turn the ignition switch ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See step 5 on page [DI-237](#)).
- Turn the ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the ignition switch ON, and wait at least for 20 seconds.
- Check the DTC (See page [DI-237](#)).

#### OK:

**DTC B0137/71 is not output.**

#### HINT:

Codes other than code B0137/71 may be output at this time, but they are not relevant to this check.

**NG**

**Replace seat belt pretensioner (LH).**

**OK**

From results of above inspection, suspected part can now be considered normal. To make sure of this, use simulation method to check. If suspected part can not be detected by simulation method, replace all SRS components including wire harness.