


DTC	P0440	Evaporative Emission Control System Malfunction
------------	--------------	--

CIRCUIT DESCRIPTION

The vapor pressure sensor, VSV for canister closed valve (CCV) and VSV for pressure switching valve are used to detect abnormalities in the evaporative emission control system.


The ECM decides whether there is an abnormality in the evaporative emission control system based on the vapor pressure sensor signal.

DTC P0440 is recorded by the ECM when evaporative emissions leak from the components within the dotted line in Fig. 1 below, or when the vapor pressure sensor malfunctions.



DTC No.	DTC Detection Condition	Trouble Area
P0440	Fuel tank pressure is atmospheric pressure after vehicle is driven for 20 min. (2 trip detection logic)	<ul style="list-style-type: none"> • Hose or tube cracked, holed, damaged or loose seal ((3) in Fig. 1) • Fuel tank cap incorrectly installed • Fuel tank cap cracked or damaged • Vacuum hose cracked, holed, blocked, damaged or disconnected ((1) or (2) in Fig. 1) • Fuel tank cracked, holed or damaged • Charcoal canister cracked, holed or damaged • Open or short in vapor pressure sensor circuit • Vapor pressure sensor • Fuel tank over fill check valve cracked or damaged • ECM

WIRING DIAGRAM




INSPECTION PROCEDURE

HINT:

- If DTC P0441, P0446, P0450 or P0451 is output after DTC P0440, first troubleshoot DTC P0441, P0446, P0450 or P0451. If no malfunction is detected, troubleshoot DTC P0440 next.
- Ask the customer whether, after the MIL came on, the customer found the fuel tank cap loose and tightened it. Also ask the customer whether the fuel tank cap was loose when refuelling. If the fuel tank cap was not loose, the DTC is suspected. If the fuel tank cap was not loose or if the customer was not sure if it was loose, troubleshoot according to the following procedure.
- Read freeze frame data using TOYOTA hand-held tester or OBD II scan tool. Because freeze frame records the engine conditions when the malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.
- When the ENGINE RUN TIME in the freeze frame data is less than 200 seconds, carefully check the VSV for EVAP, charcoal canister and vapor pressure sensor.

- 1 Check whether hose close to fuel tank have been modified, and check whether there are signs of any accident near fuel tank or charcoal canister.**

**CHECK:**

Check for cracks, deformation and loose connection of the following parts:

- Fuel tank
- Charcoal canister
- Fuel tank filler pipe
- Hoses and tubes around fuel tank and charcoal canister

NG**Repair or replace.****OK**

- 2 Check that fuel tank cap is TOYOTA genuine parts.**

NG**Replace with TOYOTA genuine parts.****OK**

- 3 Check that fuel tank cap is correctly installed.**

NG**Correctly install fuel tank cap.****OK**

- 4 Check fuel tank cap (See page [EC-6](#)).**

NG**Replace fuel tank cap.****OK**

5	Check fuel inlet pipe for damage.
----------	--

PREPARATION:

Remove the fuel tank cap.

CHECK:

Visually inspect the fuel inlet pipe for damage.

NG	Replace fuel inlet pipe.
-----------	---------------------------------

OK

6	Check vacuum hoses between vapor pressure sensor and fuel tank, and charcoal canister and VSV for pressure switching valve.
----------	--

CHECK:

- (a) Check that the vacuum hose is connected correctly.
- (b) Check the vacuum hose for looseness and disconnection.
- (c) Check the vacuum hose for cracks, hole and damage.

NG	Repair or replace.
-----------	---------------------------

OK

7	Check hose and tube between fuel tank and charcoal canister.
----------	---

CHECK:

- (a) Check for proper connection of the fuel tank and fuel evap pipe (See page [EC-6](#)), fuel evap pipe and fuel tube under the floor, fuel tube under the floor and charcoal canister.
- (b) Check the hose and tube for cracks, hole and damage.

NG	Repair or replace.
-----------	---------------------------

OK

8	Check charcoal canister for cracks, hole and damage (See page EC-6).
----------	---

NG	Replace charcoal canister.
-----------	-----------------------------------

OK


- 9** Check voltage between terminals VC and E2 of ECM connector (See page [DI-37](#), step 5).

NG

Check and replace ECM (See page [IN-28](#)).

OK

- 10** Check voltage between terminals PTNK and E2 of ECM connectors.



PREPARATION:

- (a) Disconnect the ECM with connector from body panel (See page [SF-62](#)).
- (b) Remove the fuel tank cap.
- (c) Turn the ignition switch ON.

CHECK:

Measure the voltage between terminals PTNK and E2 of the ECM connectors.

OK:

Voltage: 3.0 – 3.6 V

OK

Go to step 12.

NG

- 11** Check for open and short in harness and connector between vapor pressure sensor and ECM (See page [IN-28](#)).

NG

Repair or replace harness or connector.

OK

Replace vapor pressure sensor.

- 12** Check fuel tank and fuel tank over fill check valve for cracks and damage.

NG

Replace fuel tank or fuel tank over fill check valve.

A button with a black border and a downward-pointing arrow shape at the bottom, containing the text "OK" in bold black font.

It is likely that vehicle user did not properly close fuel tank cap. Please explain to customer how to properly install fuel tank cap.