



# WHEEL HOUSING REINFORCEMENT (ASSY)



## REPLACEMENT

1. REMOVE SIDE PANEL NO.2 REINFORCEMENT (See page BP-74)
2. REMOVE FRAME REAR UPPER CROSSMEMBER (See page BP-62)
3. REMOVE SIDE PANEL NO.4 REINFORCEMENT (See page BP-51)
4. REMOVE WHEEL HOUSING REINFORCEMENT



**5. INSTALL WHEEL HOUSING REINFORCEMENT**

- (a) Temporarily install the new parts and measure each part in accordance with the body dimension diagram.



6. MEASURING THE ENGINE COMPARTMENT DIMENSIONS (See page BP-95)
7. INSTALL SIDE PANEL NO.4 REINFORCEMENT (See page BP-52)
8. INSTALL FRAME REAR UPPER CROSSMEMBER (See page BP-63)
9. INSTALL SIDE PANEL NO.2 REINFORCEMENT (See page BP-75)
10. APPLYING SEALER TO THE INSIDE OF THE VEHICLE (See page PC-1)
11. APPLYING SEALER TO THE ENGINE COMPARTMENT (See page PC-1)
12. APPLYING ANTI-RUST AGENT
  - (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structural weld spots.