

<b>DTC</b>	<b>C1553/53</b>	<b>When resetting voltage, vehicle is being driven</b>
------------	-----------------	--

## CIRCUIT DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
C1553/53	ECU internal malfunction	• Vane pump assembly with motor

Fail safe function:

If there is resetting of the voltage of the vane pump assembly with motor, the vane pump assembly with motor prohibits the EHPS system from operating.

## INSPECTION PROCEDURE

HINT:

- In case the ECU detects that the ignition switch turns ON – OFF – ON while driving and starting the system, DTC C1553/53 is output.
- Stop the vehicle and start the system by turning the ignition switch OFF – ON. Then DTC 1553/53 will not be output.

<b>1</b>	<b>Check output DTC C1553/53 when turning the ignition switch from OFF to ON.</b>
----------	---

**YES**

**Check and replace vane pump assembly with motor.**

**NO**

**Clear DTC.**