


TERMINALS OF ECU



Symbols (Terminal No)	Wiring Color	Condition	STD Voltage (V)
B (B5-14) – E (B5-25)	L-R – W-B	Always	9 – 14
IG (B5-15) – E (B5-25)	R-B – W-B	Ignition switch OFF	Below 1
		Ignition switch ON	9 – 14
KSW (B5-19) – E (B5-25)	Y-R – W-B	Key is inserted	Below 1
		Key is not inserted	9 – 14
BDR1 (B6-13) – E (B5-25)	W-L – W-B	Always	9 – 14
BDR2 (B6-14) – E (B5-25)	B – W-B	Always	9 – 14
DMUP (B6-5) – E (B5-25)	R – W-B	Ignition switch ON, Driver power window is not operating	Below 1
		Ignition switch ON, Driver power window is operating to upward	9 – 14
DMDW (B6-4) – E (B5-25)	G – W-B	Ignition switch ON, Driver power window is not operating	Below 1
		Ignition switch ON, Driver power window is operating to downward	9 – 14
L (B6-11) – E (B5-25)	L – W-B	Always	9 – 14
PWE (B6-12) – E (B5-25)	L-O – W-B	Driver power window is not operating	Below 1
		Driver power window is operating to upward	9 – 14
DU (B5-12) – E (B5-25)	L-B – W-B	Driver power window is not operating	Below 1
		Driver power window is operating to upward	9 – 14
DDN (B5-24) – E (B5-25)	L – W-B	Driver power window is not operating	Below 1
		Driver power window is operating to downward	9 – 14
AUTO (B6-9) – E (B5-25)	L-O – W-B	Auto down switch OFF	Below 1
		Ignition switch ON, Auto down switch ON	9 – 14
LSWD (B5-21) – E (B5-25)	R-W – W-B	Driver door is unlocked	Below 1
		Driver door is locked	Approx. 5.7
LSWP (B5-23) – E (B5-25)	G-W – W-B	Passenger door is unlocked	Below 1
		Passenger door is locked	Approx. 5.7
L1 (B6-6) – E (B5-25)	BR-W – W-B	Door lock manual switch OFF or UNLOCK	Below 1
		Door lock manual switch LOCK	Approx. 5.0
UL1 (B6-15) – E (B5-25)	G-B – W-B	Door lock manual switch OFF	Below 1
		Door lock manual switch UNLOCK	Approx. 5.0
L2 (B6-7) – E (B5-25)	L-W – W-B	Door key lock and unlock switch OFF	Approx. 5
		Door key lock and unlock switch ON	Below 1
UL2 (B6-17) – E (B5-25)	L-Y – W-B	Passenger door key lock and unlock switch OFF	Approx. 5.0
		Passenger door key lock and unlock switch ON	Below 1
UL3 (B6-16) – E (B5-25)	L-Y – W-B	Driver door key lock and unlock switch OFF	Approx. 5.0
		Driver door key lock and unlock switch ON	Below 1

ACT+ (B5-13) – E (B5-25)	L-R – W-B	Door lock is operating to lock	9 – 14
ACT- (B5-1) – E (B5-25)	L-B – W-B	Door lock is operating to unlock	9 – 14
DCTY (B6-10) – E (B5-25)	R-W – W-B	Driver door opened	Below 1
		Driver door closed	9 – 14
PCTY (B6-2) – E (B5-25)	R – W-B	Passenger door opened	Below 1
		Passenger door closed	9 – 14