

TRANSMISSION SERVICING - M/T

Article Text

1988 Toyota MR2

For Rse 555 Main Street Clarksville Va 22901

Copyright © 1997 Mitchell International
Thursday, February 14, 2002 03:56PM

ARTICLE BEGINNING

1988 MANUAL TRANSMISSION SERVICING

Toyota

**Camry, Celica, Corolla, Cressida, MR2,
Pickup/4Runner, Supra, Tercel, Van/Wagon**

IDENTIFICATION

TOYOTA MANUAL TRANSMISSION APPLICATIONS TABLE

Camry

2WD 5-Speed - Model E52 & S51 Transaxle
4WD All-Trac 5-Speed - Model E56F Transaxle

Celica

2WD 5-Speed - Model S53 Transaxle
4WD All-Trac 5-Speed - Model E50F2 Transaxle

Corolla 5-Speed - Model C50 & C52 Transaxle

MR 2 5-Speed - Model C52 & E51

Pickup & 4Runner

2WD 4-Speed - Model W46 & G40
 2WD 5-Speed - Model W55, G57 & R150 (Turbo)
 4WD 5-Speed - Model W56 & R150E (V6)

Supra 5-Speed Model W55 & R1551 (5) **5-Speed - Model R1554 & W58**

Supra 5-Speed - Model R134 & W58
Tercel Sedan 4-Speed - Model C140 & C141
 5-Speed - Model C150

Tercel Wagon 5-Speed Model C150 6-Speed Model Z54E

Terrell Wagon 3-speed - Model 2544

5-Speed - Model G53

2WD 5-Speed - Model G53
4WD 5-Speed - Model G53F

LUBRICATION

SERVICE INTERVALS

Check lubricant level every 20,000 on all except 4WD Pickups.
On 4WD Pickups, check every 15,000 miles. Replace fluid if vehicle is
operated in severe service conditions.

CHECKING FLUID LEVEL

Transmission

Check lubricant level at fill plug hole. Lubricant should be

to bottom of hole. Transmission on Tercel Wagon has 2 drain plugs on bottom of transaxle.

Transfer Case (Except Tercel Wagon)

Drain plugs on 4WD transfer cases are separate from main transmission case.

Transfer Case (Tercel Wagon)

The integral differential and transaxle assembly on Tercel Wagons have separate drain and fill plugs. See Fig. 1. When filling with fluid, leave extension housing drain plug loose about 7 or 8 turns. After filling, tighten drain plug.




Fig. 1: Tercel Wagon Transaxle & Differential Drain & Fill Plugs
Courtesy of Toyota Motor Sales, U.S.A., Inc.

RECOMMENDED FLUID

All transmissions (except S51 and S53) use API GL-4 or GL-5, SAE 75W-90 or 80W-90. The S51 and S53 transmissions use Dexron II ATF.

FLUID CAPACITY

TRANSMISSION REFILL CAPACITIES TABLE

Application	Qts. (L)
Camry	

E52	4.4 (4.2)
S51 (1)	2.7 (2.6)
E56F	5.3 (5.0)
Celica		
S53 (1)	2.7 (2.6)
E50F2	5.1 (4.8)
Corolla		
C50 & C52	2.7 (2.6)
MR2		
C52	2.7 (2.6)
E51	4.8 (4.2)
Pickup & 4Runner		
2WD		
G40 & G57	2.3 (2.2)
W46, W55 & W56	2.5 (2.4)
2WD & 4WD		
R150	2.7 (2.6)
4WD		
W56	3.2 (3.0)
Supra		
R154	3.2 (3.0)
W58	2.5 (2.4)
Tercel		
C140 & C141	2.5 (2.4)
C150	2.5 (2.4)
Z54F	4.1 (3.9)
Van		
G53	2.3 (2.2)
G53F	2.8 (2.6)

(1) - Use Dexron II ATF.

AA

ADJUSTMENTS

LINKAGE

Shift Lever Free Play (Camry, Celica & Corolla)

1) Select a shim that allows a preload of 1.6-3.2 oz. (50-100 g) at the top of shift lever. See Fig. 2. Install shim in shift lever seat.

2) Shims are available from .3-1.2 mm in .1 mm increments.

The .3 mm shim is marked with "A" or "3" while the .4 mm shim is marked with "B" or "4". All other shims are similarly marked up to the 1.2 mm shim ("L" or "12").




Fig. 2: Checking Shift Lever Preload
Courtesy of Toyota Motor Sales, U.S.A., Inc.

Shift Lever (Van)

- 1) Remove shifter console box. Ensure shift lever is in Neutral position. Check if a .24" (6 mm) diameter pin inserts easily into shift lever retainer hole and shift lever inspection hole.
- 2) To adjust shift lever Neutral position, loosen adjusting lock nuts on select control cable. See Fig. 3. Adjust length of select control cable so that guide pin inserts smoothly into all holes.
- 3) Tighten adjusting lock nuts. Remove guide pin and install console box.

NOTE: Models not listed do not require adjustment.




Fig. 3: Adjusting Van Shift Lever Neutral Position
Courtesy of Toyota Motor Sales, U.S.A., Inc.

END OF ARTICLE