



BODY INSPECTION

MA03R-01

1. TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

Tighten these parts:

- Seat-to-body mounting bolts

Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)

- Rear suspension member-to-body mounting bolts

Torque: 80 N·m (816 kgf·cm, 59 ft·lbf)

2. BODY INSPECTION

- Check the body exterior for dents, scratches and rust.
- Check the underbody for rust and damage.

If necessary, replace or repair.

3. ROAD TEST

- Check the engine and chassis for abnormal noises.
- Check that the vehicle does not wander or pull to one side.
- Check that the brakes work properly and do not drag.
- Do setting of the parking brake shoes and drum.

4. FINAL INSPECTION

- Check the operation of the body parts:
 - Front hood
 - Auxiliary catch operates properly
 - Hood locks securely when closed
 - Doors
 - Door locks operate properly
 - Doors close properly
 - Engine hood
 - Door lock operates properly
 - Seat adjusts easily and locks securely in any position
 - Seat back locks securely in any position
- Be sure to deliver a clean car.

Especially check:

 - Steering wheel
 - Shift lever knob
 - All switch knobs
 - Seats