



## CAMSHAFT TIMING OIL CONTROL VALVE

SF0SL-10

### ON-VEHICLE INSPECTION

#### INSPECT CAMSHAFT TIMING OIL CONTROL VALVE (OCV) RESISTANCE

- Disconnect the ocv connector.
- Using an ohmmeter, measure the resistance between the terminals.

**Resistance: 6.9 – 7.9  $\Omega$  at 20°C (68°F)**

If the resistance is not as specified, replace the ocv.

- Reconnect the ocv connector.