1994 ELECTRICAL Fuses & Circuit Breakers - MX-5 Miata

1994 ELECTRICAL


Fuses & Circuit Breakers - MX-5 Miata

IDENTIFICATION

CAUTION: When battery is disconnected, vehicle computer and memory systems may lose memory data. Driveability problems may exist until computer systems have completed a relearn cycle. See COMPUTER RELEARN PROCEDURES article in GENERAL INFORMATION before disconnecting battery.

MAIN FUSE BLOCK

Main fuse block is located on passenger's side of engine compartment. See $\underline{Fig. 1}$.




G00130712

Fig. 1: Locating Main Fuse Block

1994 ELECTRICAL Fuses & Circuit Breakers - MX-5 Miata

Courtesy of MAZDA MOTORS CORP.



G00130713

Fig. 2: Identifying Main Fuse Block Components Courtesy of MAZDA MOTORS CORP.

POSITION		DESCRIPTION	COLOR	CIRCUIT PROTECTED	
1	HEAD	30A	Pink	Headlights	
2	INJ	30A	Pink	Pink Fuel injection, Alternator	
3	MAIN	80A	Black	ack For protection of all circuits	
4	BTN	40A	Green	Refer to HAZARD (15A), STOP (15A), ROOM (10A), TAIL (15A)	
5	ABS*	60A	Yellow	Antilock brake system	
6	COOLING FAN	30A	Pink	Cooling fan	
7	AIR BAG	10A	Red	Air bag	
8	AD FAN*	20A	Yellow	Additional fan (Air conditioner)	
9	ST SIG	10A	Red	Fuel injection	
10	RETRACTOR	30A	Green	Headlight retractor	

G00130706

Fig. 3: Main Fuse Block Legend Courtesy of MAZDA MOTORS CORP.

1994 ELECTRICAL Fuses & Circuit Breakers - MX-5 Miata

FUSE BLOCK

Fuse block is located under driver's side of instrument panel. See Fig. 4.




Fig. 4: Locating Fuse Block Courtesy of MAZDA MOTORS CORP.

1994 ELECTRICAL Fuses & Circuit Breakers - MX-5 Miata




Fig. 5: Identifying Fuse Block Components Courtesy of MAZDA MOTORS CORP.

1994 ELECTRICAL Fuses & Circuit Breakers - MX-5 Miata

	POSITION	DESCRIPTION	COLOR	CIRCUIT PROTECTED	
A	ENGINE	15A	Blue	Cooling fan	
В	METER	10A	Red	Gauges, Warning lights, Turn-signal lights, Cruise control	
C	AIR BAG	15A	Blue	Air bag	
D	HEATER	30A	_	Heater	
E	_	_	_		
F	POWER WIND*	30A	Green	Power windows	
G	WIPER	20A	Yellow	Wipers, Washer	
Н	_	_			
I	TAIL	15A	Blue	Taillights	
J				-	
K	STOP	15A	Blue	Shift lock, Cruise control, Horn, Stoplights	
L	HAZARD	15A	Blue	Hazard warning lights	
M					
N	ROOM	10A	Red	Red Interior lamps, Warning buzzers, Radio/cassette and compact disc player and clock	
0	CIGAR	15A	Blue	Radio/cassette and compact disc player and clock, Cigarette lighter	
P					
Q					

G00130709

Fig. 6: Fuse Block Legend Courtesy of MAZDA MOTORS CORP.

TRUNK FUSE PANEL

Trunk fuse panel is located on passenger's side of trunk. See $\underline{Fig. 7}$.

1994 ELECTRICAL Fuses & Circuit Breakers - MX-5 Miata





Fig. 7: Locating Trunk Fuse Panel Courtesy of MAZDA MOTORS CORP.

1994 ELECTRICAL Fuses & Circuit Breakers - MX-5 Miata



▼ Fuse panel (Trunk)

POSITION		DESCRIPTION	COLOR	CIRCUIT PROTECTED
1	DEFOG*	10A	Red	Rear defroster
2	ANTENNA*	10A	Red	Auto antenna

^{*}Some models.

G00130719

Fig. 8: Identifying Trunk Fuse Panel Components & Legend Courtesy of MAZDA MOTORS CORP.