



FRONT APRON TO COWL SIDE UPPER MEMBER (ASSY) REPLACEMENT

1. REMOVE FRONT FENDER APRON LOWER GUSSET (See page BP-36)
2. REMOVE FRONT APRON TO COWL SIDE UPPER MEMBER



3. INSTALL FRONT APRON TO COWL SIDE UPPER MEMBER**HINT:**

Inspect the fitting of the front fender and hood, etc. before welding, since this affects the appearance of the finish.



-
4. MEASURING THE FRONT LUGGAGE COMPARTMENT DIMENSIONS (See page BP-95)
 5. INSTALL FRONT FENDER APRON LOWER GUSSET (See page BP-37)
 6. APPLYING SEALER TO THE FRONT LUGGAGE COMPARTMENT (See page PC-1)
 7. APPLYING ANTI-RUST AGENT
 - (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structural weld spots.