



REASSEMBLY

1. COAT PISTON WITH LITHIUM SOAP BASE GLYCOL GREASE, AS SHOWN
2. INSTALL PISTON AND SPRING INTO CYLINDER
3. INSTALL BOOT AND PUSH ROD
 - (a) Install the push rod to the boot.
 - (b) Install the boot with the push rod to the cylinder.