


ENGINE COMPARTMENT

(Three Dimensional Distance)



HINT: For symbols, capital letters indicate right side of vehicle, small letters indicate left side of vehicle (Seen from rear).

mm (in.)

Symbol	Name	Hole dia.	Symbol	Name	Hole dia.
	Quarter panel installation nut	6 (0.24) nut		Rear floor side member standard hole	12 (0.47)
	Rear spring support hole – inner	11 (0.43)		Lower back side panel standard hole	10 (0.39)
	Quarter panel installation nut	6 (0.24) nut		Rear floor side rear member standard hole	13 (0.51)
	Rear suspension upper brace installation nut	10 (0.39) nut		Lower back panel standard hole	10 (0.39)
	Rear floor side member standard hole	15 (0.59)		Hood hinge installation nut	8 (0.31) nut