





FRONT FENDER APRON (ASSY)

REPLACEMENT

1. REMOVE RADIATOR UPPER SIDE SUPPORT (See page BP-1)
2. REMOVE FRONT FENDER APRON LOWER GUSSET (See page BP-36)
3. REMOVE FRONT FENDER APRON





4. INSTALL FRONT FENDER APRON**HINT:**

Inspect the fitting of the front fender and hood, etc. before welding, since this affects the appearance of the finish.

- (a) Temporarily install the new parts and measure each part in accordance with the body dimension diagram.

HINT:

Make sure each measurement is correct, as this parts affects the front wheel alignment.




RH: 1-4
LH: 1-2



[LH only] 1-5

RH: 1-15
LH: 1-17



5. MEASURING THE FRONT LUGGAGE COMPARTMENT DIMENSIONS (See page BP-95)
6. MEASURING THE UNDER BODY DIMENSIONS (See page BP-95)
7. INSTALL FRONT FENDER APRON LOWER GUSSET (See page BP-37)
8. INSTALL RADIATOR UPPER SIDE SUPPORT (See page BP-2)
9. APPLYING SEALER TO THE FRONT LUGGAGE COMPARTMENT (See page PC-1)
10. APPLYING UNDER COATING (See page PC-6)
11. APPLYING ANTI-RUST AGENT
 - (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structural weld spots.