

DTC	B2798/99	Communication Malfunction No. 2
------------	-----------------	--

CIRCUIT DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
B2798/99	Communication error	<ul style="list-style-type: none"> • Key • Transponder key amplifier • Wire harness • ECM

WIRING DIAGRAM

Refer to DTC B2796/99 on page [DI-345](#).

INSPECTION PROCEDURE

1	Check harness and connector between transponder key amplifier and ECM.
----------	---

NG

Repair or replace harness or connector.

OK

2	Does it operate normally after replacement of transponder key amplifier?
----------	---

Yes

Replace transponder key amplifier.

No

Check and replace ECM (See page [IN-28](#)).